UltraStat Original Dry Adhesive

UltraStat® Original Dry Adhesive is a full surface textile re-enforced double sided self stick roll flooring adhesive. It is VOC free, free of odors, carcinogens, out-gassing and is totally safe for people. The adhesive is acrylic based, plasticizer resistant, contains no formaldehydes and has unrestricted waste disposal. UltraStat® has a lower adhesive strength to the old flooring and a high strength adhesion to the new flooring. Installations (i.e. carpet tile over access floors, trenches, or old carpet) are releasable. (See restrictions in detailed installation instructions).

Availability:
7700-100025 Rolls 39.5" x 82'6" (1 m x 25 m)
7700-50025 Rolls 19.5" x 82'6" (50 cm x 25 m

Applications:
Sub-floors
UltraStat® may be installed only over dry (<3.0 lb/1000 sft.) structurally sound firm dust and oil-free surfaces, such as concrete, old glue-down carpet, VAT, vinyl composition tile, homogeneous vinyl sheet or tile, poured epoxy, ceramic, stone or terrazzo. It may be used over steel or HPL covered access floors. It may be used over wood and parquet, plywood and laminates only if these sub-floors are free of acrylic finishes and are not directly installed over on-grade or below-grade concrete without an air space between the concrete and the wood products (Moisture!!). Dry adhesive may not be used over gypsum patches. Not suitable for outdoor installations.

New Flooring
Ultra® may be used to adhere carpet with jute, Action Bac®, SBR foam back, Unibond and carpet tile with glass fiber reinforced vinyl backings or bituminous backings. It is also used to install solid vinyl sheet or tile.

Unsuitable New Flooring
Dimensionally non-stable flooring products, rubber sheet or tile, vinyl composition tile (dusty back), wood or laminate floors, cork, cocos are not suitable. Certain recycled rubber flooring has limited suitability. Recycled EPDM based rubber is not suitable.

Advantages of Installation with Ultra® Dry Adhesive:
Save the dust, debris, expense of disposal of old flooring and re-prepping of old sub-floors necessitated by tear out. Dry adhesive has no open time. It can be laid directly over old floors. Vinyl may be heat welded immediately. Installations may be subjected to rolling loads and heavy traffic without waiting.

Installation:
Roll out Ultra® perpendicular to new flooring. Overlap and double cut seams. For carpet over carpet use Ultraconstruction tape to re-enforce perimeters and seams beneath the Ultra®. Unroll new carpet or vinyl, seam seal as per manufacturer's specifications. Roll and put into service.

CAUTION
Request Detailed Installation Instructions and conduct tests before installation.

4916 26th Street West, Suite 100, Bradenton, Florida 34207
Toll Free 877-GND-ZERO (463-1376), **Direct Phone** 941-751-7581 **Fax** 1-941-751-7586
Email sales@gndzero.com
http://www.gndzero.com

4916 26th Street West, Suite 100, Bradenton, Florida 34207
Toll Free 877-GND-ZERO (463-1376), **Direct Phone** 941-751-7581 **Fax** 1-941-751-7586
Email sales@gndzero.com
http://www.gndzero.com