MTR-8900 Software Installation

The MTR-8900 combo-tester/data logger improves efficiency and guarantees a static safe environment with the fail-proof system. In less than 3 seconds, this meter automatically and simultaneously tests, prints, records, and e-mails the exact resistivity value of both heel grounders and wrist straps.

- Saves Time with Speedy Log-Ins
- Eliminates Error
- Protects and Ensures Product Quality
- Identifies and Fails 'Out of Spec' Employees
- Accurately Records and Manages Data

System Requirements:

Windows: Windows 95, 3.1 or greater. PC Compatible 386 or greater. 4xCD-ROM, 4MB RAM, 10 MB free hard disk space. Windows NT: 3.51 or greater running either Intel, or IBM Power PC.

Note: check with your local distributor or Ground Zero Electrostatics, Inc. to learn about available options like networking, link to door/carousel (denies failed testers), increased employee capacity, and much more.

Installation Instructions

WINDOWS 95, 98, 2000, XP AND NT 4.0 WORKSTATION

1. Insert the CD disk into CD-ROM drive.
2. Follow the direction on the screen.
3. If no directions appear, follow Windows 3.1 instructions below.

WINDOWS 3.1/NT 3.51

1. Start Windows
2. Place the CD disk in CD-ROM drive.
3. Under "file Manager' window, select "run..." from menu.
4. In the "run..." dialog box, type, "D:SET UP" (D is the letter of the CD-ROM drive containing the ESD Test Software). Click, "OK"
5. Follow the on-screen instructions.
6. To begin the ESD Test Software, double click on the ESD Test Software Icon.