



Ground Zero Electrostatics STATIC DISSIPATIVE LAUDERING INSTRUCTIONS

RECOMMENDED LAUDERING INSTRUCTIONS

The following precautions are recommended when washing or dry-cleaning polyester static-dissipative garments:

HOME WASH

1. Rigid inspection and repair of all defects before washing. If repairs or alterations are necessary, use continuous filament thread.
2. All zippers should be zipped up.
3. Use smaller loads to decrease mechanical action.
4. Use less harsh soap (mild alkaline or neutral soaps) or detergents.
5. Use no bleach, starch or fabric softener if possible. If bleach must be used, reduce the concentration as much as possible.
6. Reduce the washing temperature below 140°F for colors, and not more than 160°F for whites. End the washing cycle with a cold rinse.
7. Use short, low speed extraction.
8. Tumble dry at "permanent press" (175°F to 200°F exhaust stack temperature) setting Use at least a 5 minute cold tumble at the end of the drying cycle for proper cool down. Remove and hang garments immediately.
9. Use ironing only as a last resort. If ironing is necessary, do not overheat Polyester static-dissipative garments contain synthetic fibers that can be scorched or fused with excessive heat. Use lowest temperature.
10. Inspection before and after processing should include good light to observe any potential tinting surfaces on the garments.

DRY CLEANING

Garments may be professionally dry cleaned in either perchloroethylene or petroleum solvents.



4916 26th Street West, Suite 100, Bradenton, Florida 34207

Toll Free 877-GND-ZERO (463-1376), **Direct Phone** 941-751-7581 **Fax** 1-941-751-7586

Email sales@gndzero.com

http://www.gndzero.com